



DAA Software Download and Installation Instructions

Rev 2 – 3/19

Jesse Hamler

jessehamler@truckvibration.com

(931) 520-7661

Before You Begin....

1. Uninstall previous versions of DAA
2. Restart PC
3. Proceed to next page



Paste below address into Chrome address bar and hit enter...

or just click on address below...

<http://www.truckvibration.com/DAA121.zip>



Google Search


I'm Feeling Lucky






Google Search I'm Feeling Lucky


Download should begin



Right click on the downloaded zip file and select "Extract All"



1. Check "Show extracted files when complete"



2. Select "Extract"

